

## ENGINE OIL

### Engine Oil Level Check


Check the engine oil level each day before operating the ATC.

The oil filler cap (1) is on the right crankcase cover and contains a dipstick for measuring the oil level. The oil level must be maintained between the upper (2) and lower (3) level marks on the dipstick.

1. With the ATC on level ground, remove the oil filler cap/dipstick and wipe it clean.
2. Reinsert the dipstick without screwing it in. Remove the oil filler cap/dipstick again and check the oil level.
3. If required, add the specified oil up to the upper level mark. Do not overfill.
4. Reinstall the filler cap/dipstick.

#### **CAUTION :**

\* *Running the engine with insufficient oil can cause serious engine damage.*



(1) Oil filler cap/dipstick (3) Lower level mark  
(2) Upper level mark