

Rear Suspension Inspection

Check the rear suspension periodically by careful visual examination. Note the following items.

1. Rear fork bushing—this can be checked by pushing hard against the side of the rear wheel while the motorcycle is on the center stand and feeling for looseness of the fork bushings.
2. Check side stand spring for damage and fitness.
3. Check all suspension component attachment points for security of their respective fasteners.

NOTE:

If any sign of wear or damage is noticed, consult your Honda dealer for further inspection.

Battery Maintenance

Battery electrolyte:

The battery is mounted under the seat, and is accessible by releasing the seat lock and raising the seat.

Raise the battery slightly to check the battery electrolyte.

Battery electrolyte level should be checked every 3 months. The electrolyte level must be maintained between the upper ③ and lower ④ level marks on the side of the battery. If the electrolyte level is found to be low, remove the battery filler caps and carefully add distilled water until the electrolyte level in each cell is between the upper and lower level marks.

Use a small syringe or plastic funnel to add water. Only distilled water should be added to avoid contaminating the electrolyte.