

Check for worn wheel bearing by grabbing the rear wheel, and attempting to move the wheel side to side. Replace the bearings if any looseness is noted (page 15-6).



NUTS, BOLTS, FASTENERS

Check that all chassis nuts and bolts are tightened to their correct torque values (page 1-13).
Check that all safety clips, hose clamps and cable stays are in place and properly secured.

WHEELS/TIRES

NOTE:

Tire pressure should be checked when the tires are COLD.

RECOMMENDED TIRE PRESSURE AND TIRE SIZE:

Driver only:

Front: 200 kpa (2.00 kgf/cm², 29 psi)

Rear: 200 kpa (2.00 kgf/cm², 29 psi)

Driver and passenger:

Front: 200 kpa (2.00 kgf/cm², 29 psi)

Rear: 225 kpa (2.25 kgf/cm², 33 psi)



Check the tires for cuts, embedded nails, or other damage. Check the front and rear wheels for trueness (refer to section 14 and 15).

Check the tread depth.

Replace the tires when the tread depth reaches the following limits.

MINIMUM TREAD DEPTH: To the indicator