

Is Your ATV Ready to Ride?

Tyres Use a gauge to check the air pressure. Adjust if needed. Also look for signs of damage or excessive wear (page 130).

Nuts & Bolts Check the wheels to see that the axle nuts are tightened. Use a wrench to make sure all accessible nuts, bolts, and fasteners are tight.

Underbody & Exhaust System Check for, and remove, any dirt, vegetation or other debris that could be a fire hazard or interfere with the proper operation of the vehicle.

Air Cleaner Housing Drain Tube Check for deposits in the drain tube. If necessary, clean the tube (page 102) and check the air cleaner housing.

Leaks, Loose Parts Walk around your ATV and look for anything that appears unusual, such as a leak or loose cable.

Cable Check the cable housings for wear. Check the fittings for looseness. Replace or tighten as needed.

Check these items after you get on the ATV:

Throttle Check the freeplay and adjust if needed. Press the throttle to make sure it moves smoothly without sticking, and snaps shut automatically when it is released, in all steering positions (page 103).