

Storing Your Honda

9. Inflate the tyres to their recommended pressures (page 138).
10. Store your ATV in an unheated area, free of dampness, away from sunlight, with a minimum of daily temperature variation.
11. Place your ATV on blocks to lift all tyres off the floor.
12. Cover your ATV with a porous material. Avoid using plastic or similar non-breathing, coated materials that restrict air flow and allow heat and moisture to accumulate.

Removal from Storage

Refer to *Safety Precautions* on page 94.

1. Uncover and clean your ATV.
2. If your ATV has been stored for more than four months — change the engine oil (page 113).
3. If your ATV has been stored for more than two months — ask your dealer to drain and replace the fuel.
4. Charge the battery (page 155) as required. Install the battery.
5. Lubricate the drive chain (page 150).
6. Perform a pre-ride inspection (page 44), then test-ride your ATV at low speeds.

Tips 169