



## Spark Plugs

5. With the plug washers attached, thread the spark plugs in by hand to prevent cross-threading.
6. Tighten each spark plug:
  - If the old plug is good:
    - 1/8 turn after it seats.
  - If installing a new plug, tighten it twice to prevent loosening:
    - a) First, tighten the plug:
      - NGK: 3/4 turn after it seats.
      - DENSO: 1/2 turn after it seats.
    - b) Then loosen the plug.
    - c) Next, tighten the plug again:
      - 1/8 turn after it seats.

### NOTICE

*Improperly tightened spark plugs can damage the engine. If a plug is too loose, a piston may be damaged. If a plug is too tight, the threads may be damaged.*

7. Reinstall the spark plug caps. Take care to avoid pinching any cables or wires.
8. Install the remaining parts in the reverse order of removal.