


Seat Removal

Refer to *Safety Precautions* on page 45 .



(1) clips
(2) screws

(3) bolts
(4) seat

Removal

1. Remove the clips (1) and screws (2) on the fuel tank shroud.
2. Remove the bolts (3) under the rear fender.
3. Slide the seat (4) with fuel tank shroud and rear cowl back.

Installation

1. Position the prongs under the seat into the spaces for them in the frame.
2. Install the bolts and screws and tighten them, then install the clips.