

Fuse Replacement


The main fuse (1), located near the rear brake reservoir behind the right side cover is 30 A.

The fuse box (3) is located the left inner cover the specified fuses are 10 A and 15 A.

When frequent fuse failure occurs, it usually indicates a short circuit or an overload in the electrical system. See your authorized Honda dealer for repair.

CAUTION: Turn the ignition switch OFF before checking or replacing fuses to prevent accidental short-circuiting.

- (1) Main fuse
- (2) Wire coupler



Remplacement de fusible

Le fusible principal (1) situé près de la batterie sur le câble positif, est de 30A. La boîte à fusibles (3) se trouve en-dessous des instruments. Les fusibles spécifiés sont de 10A et de 15A.

En cas de pannes de fusible fréquentes, il y a sans doute un court-circuit ou une surcharge dans le circuit électrique. Voir votre concessionnaire autorisé Honda pour la réparation.

PRÉCAUTION: Placer le commutateur d'allumage sur la position OFF avant une vérification ou un remplacement des fusibles pour éviter tout risque de court-circuit accidentel.

- (1) Fusible principal
- (2) Coupleur de fil

