Maintenance Component Locations

hot start lever

front brake fluid reservoir

clutch lever

front brake lever

throttle grip

radiator cap

fuel fill cap

crankcase breather tube

air cleaner

rear suspension high speed damping adjuster
rear suspension low speed damping adjuster

front suspension compression damping adjuster

rear brake fluid reservoir

choke knob

rear suspension spring pre-load adjuster

spark plug

steering damper adjuster

front brake caliper

rear brake caliper

engine oil drain bolt

transmission oil check bolt

transmission oil filler cap

engine oil filler cap/ dipstick

engine oil filter

throttle stop screw (engine idle speed)

transmission oil drain bolt

drive chain

rear suspension rebound damping adjuster

rear brake pedal

front suspension rebound damping adjuster