

#### Trip preset buttons (4):

These buttons are used to preset mileage to your destination. Set mileage by pressing and releasing each button until the desired preset mileage is obtained. If, for example, your destination was 324 miles away, you would press and release the 100 button three times, the 10 button twice, and the 1 button four times; this would preset your tripmeter at 324.0 miles, and depending on which Trip Mode was chosen, would either count up or down from this mileage.

**NOTE: Tenths-of-a mile cannot be preset.**

#### Trip reset button (5):

Pressing and holding this button resets the tripmeter to 0.0 miles.

---

#### Botones de preselección para cada viaje (4):

Estos botones se utilizan para preseleccionar las millas hasta el punto de destino. Preselecciones las millas presionando y soltando cada botón hasta que se obtengan las millas preseleccionadas deseadas. Por ejemplo, si su punto de destino está a 324 kilómetros de distancia Vd. presionará y soltará el botón de 100 tres veces, el botón de 10 dos veces y el botón de 1 cuatro veces; así se preseleccionará su cuenta-kilómetros para cada viaje en 324 kilómetros y dependiendo de qué tipo de viaje se ha escogido, sumará o restará estas millas.

**NOTA: No se pueden preseleccionar décimos de millas.**

#### Botón de ajuste de viaje (5):

Presionando y manteniendo presionado este botón se ajusta el cuentakilómetros para cada viaje a 0,0 kilómetros.