

8. Cover the motorcycle (don't use plastic or other coated materials) and store in an unheated area, free of dampness with a minimum of daily temperature variation. Do not store the motorcycle in direct sunlight.

Removal from Storage

1. Uncover and clean the motorcycle. Change the engine oil if more than 4 months have passed since the start of storage.
 2. Check the battery electrolyte level and charge the battery as required. Install the battery.
 3. Drain any excess aerosol rust-inhibiting oil from the fuel tank. Fill the fuel tank with fresh gasoline.
 4. Perform all Pre-ride Inspection checks (page 88). Test ride the motorcycle at low speeds in a safe riding area away from traffic.
-

8. Recouvrir la machine (n'utiliser ni plastique ni matière enduite) et la remiser en un lieu faiblement chauffé, à l'abri de l'humidité et supportant des amplitudes de température quotidiennes limitées. Ne pas abandonner la motocyclette exposée aux rayons du soleil.

Remise en service

1. Découvrir et nettoyer la motocyclette. Changer l'huile du moteur si plus de quatre mois se sont écoulés depuis le début du remisage.
2. Contrôler le niveau d'électrolyte et charger la batterie comme nécessaire. Mettre la batterie en place.
3. Vidanger le réservoir à carburant du produit anti-corrosion résiduel et le remplir de carburant.
4. Effectuer tous les contrôles préalables (page 88). Essayer la machine à faible vitesse sur parcours facile en se tenant éloigné des zones encombrées.