

## STARTING THE ENGINE

**WARNING:** Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.

### NOTE:

- \* Do not use the electric starter for more than 5 seconds at a time. Release the starter button for approximately 10 seconds before pressing it again.
- \* The electric starter will work when the transmission is in gear with the clutch disengaged.
- \* Do not flood the engine by twisting the throttle repeatedly with the ignition switch ON.

### PREPARATION

Make sure the transmission is in neutral, the engine stop switch is at RUN, and the fuel valve is ON. Insert the key and turn the ignition switch ON.

Check that the red oil pressure and fuel system warning light come on.

**CAUTION:** The fuel system warning light should go off 1–2 seconds after the ignition switch comes ON. If the light remains on, the motorcycle must be inspected by your authorized Honda dealer.

---

## DEMARRAGE DU MOTEUR

**ATTENTION:** Ne jamais faire tourner le moteur dans un endroit clos. Les gaz d'échappement contiennent du monoxyde de carbone, gaz toxique.

### NOTE:

- \* Ne pas solliciter le démarreur électrique pendant plus de 5 secondes d'affilée. Lâcher le bouton de démarrage pendant une dizaine de secondes avant de le réenfoncer.
- \* Le démarreur électrique ne fonctionne pas lorsque la boîte de vitesses est en prise au débrayé.
- \* Ne pas noyer le moteur en tournant de manière répétée la poignée des gaz avec le commutateur d'allumage sur ON.

### PREPARATION

S'assurer que la boîte de vitesses est au point-mort et que l'interrupteur d'arrêt du moteur est sur RUN, puis placer le robinet d'essence sur ON. Introduire la clé et tourner le commutateur d'allumage sur ON. S'assurer que les témoins rouges de pression d'huile et du circuit d'alimentation d'essence s'allument.

**PRECAUTION:** Le témoin du circuit d'alimentation d'essence doit s'éteindre 1 ou 2 secondes après que le commutateur d'allumage a été placé sur ON. Si le témoin reste allumé, la machine devra être contrôlée par le concessionnaire Honda.