Diagnostic code **is indicated (Code signals cannot send or receive)**

Check the power input line at the immobilizer receiver connector (page 20-11).

- Abnormal → • Open or short circuit in Yellow/Red wire
- Normal ↓

Check the ground line at the immobilizer receiver connector (page 20-11).

- Abnormal → • Open circuit in Green/Orange wire
- Normal ↓

Check the signal lines between the immobilizer receiver and ECM connectors (page 20-12).

- Abnormal → • Open or short circuit in Pink wire
  • Open or short circuit in Orange/Blue wire
- Normal → • Faulty immobilizer receiver