

### Rear Mud Guard:

Line up the line "B" with the edge of the frame body cover. Using the holes in the guard as a guide, drill eight 5.5 mm holes through the cover. Secure the guard with the plates (2) and (3), washers (8) and (9), screws (5) and nuts (7). Install the plates (3) so that the inner holes are used.

