



Apply both the front and rear brakes.

### **CAUTION**

When descending a steep grade, close the throttle fully and use both brakes to slow the motorcycle down. Avoid continuous use of the brakes which may result in overheating and reduction of braking efficiency.

### **WARNING**

Both front and rear brakes should be applied, independent use of only the front or rear brake reduces stopping performance. Excessive brake application may cause either wheel to lock, reducing control of the motorcycle.