

4. Remove the spark plug and pour one tablespoon (15–20 cc) of clean engine oil into the cylinder.
Operate the recoil starter several times to distribute the oil, then reinstall the spark plug. (Make sure the engine stop switch is OFF before operating the recoil starter.)
5. Wash and dry the Sportrax, and wax all painted surfaces.
6. Inflate the tires to their recommended pressures.
7. Place the Sportrax on blocks to raise all four tires off the ground.