

Install the both upper cowl cover.

NOTE:

Align the upper cowl covers with the meter panel bosses.

Temporarily install the special bolts.

Install the upper ends of the windscreen special bolts/nuts.

Install the trim clips.

Tighten the cap nuts while holding the special bolts.
Tighten the special bolts.



UPPER COWL

REMOVAL

Remove the following:

- Inner panel (page 2-5)
- Upper cowl cover (page 2-5)

Remove the rearview mirror pivot boot.

