

Have your tyres replaced by your dealer.  
For recommended tyres and air pressure, see  
“Specifications.” ➤ P. 104  
Follow these guidelines whenever you replace  
tyres.

- Use the recommended tyres or equivalents of the same size, construction, speed rating, and load range.
- Remember to replace the inner tube whenever you replace a tyre. The old tube will probably be stretched, and it could fail if installed in a new tyre.
- Have the wheel balanced with Honda Genuine balance weights or equivalent after the tyre is installed.

## **WARNING**

Installing improper tyres on your motorcycle can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tyres recommended in this owner’s manual.