

| I: Inspect and Clean, Adjust, Lubricate or Replace,<br>if necessary<br>C: Clean      R: Replace<br>A: Adjust |                            | INITIAL<br>SERVICE<br>PERIOD<br>(First week of<br>operation) | REGULAR<br>SERVICE<br>PERIOD<br>(Every 30<br>operating days) | Refer to<br>page |
|--|----------------------------|--|--|------------------|
|  | BATTERY                    | I  | I  | 59               |
| *  | VALVE CLEARANCE            | I  | I  | 50               |
| *  | CAM CHAIN TENSIONER        | A  | A  | 58               |
| *  | CARBURETOR                 | I  | I  | 45               |
|  | FUEL LINE                  | I: (EVERY YEAR)  |  | 44               |
| *  | FUEL FILTER                | C: (EVERY YEAR)  |  | 44               |
|  | THROTTLE OPERATION         | I  | I  | 58               |
|  | FINAL DRIVE OIL            | I: (EVERY YEAR)<br>R: (EVERY 2 YEARS)                        |  | 57               |
| *  | BRAKE SHOES                | I: (EVERY YEAR)  |  | 53               |
|  | BRAKE CONTROL LINKAGE      | I  | I  | 53               |
| *  | CLUTCH                     | A  | A  | 52               |
| *  | SPARK ARRESTER             |  | C  | 61               |
|  | ALL NUTS, BOLTS, FASTENERS | I  | I  | —                |
|  | LIGHTING EQUIPMENT         | I  | I  | —                |
|  | TIRES                      | I  | I  | 22               |
| *  | STEERING HEAD BEARING      | A: (EVERY YEAR)  |  | —                |