

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean            R: Replace A: Adjust            L: Lubricate		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	CAM CHAIN TENSIONER	A	A	50
*	CARBURETOR	I	I	37
	FUEL LINE	I: (EVERY YEAR)		36
*	FUEL FILTER	C: (EVERY YEAR)		36
	THROTTLE OPERATION	I	I	48
	DRIVE CHAIN	NOTE (2)	I, L	49
*	FRONT & REAR BRAKE SHOES	NOTE (3)	I: (EVERY YEAR)	
	FRONT & REAR BRAKE SYSTEM	I	I	45
*	CLUTCH	A	A	44
*	SPARK ARRESTER		C	51
	ALL NUTS, BOLTS, FASTENERS	I	I	—
	LIGHTING EQUIPMENT	I	I	—
	TIRES	I	I	15
*	STEERING HEAD BEARING	A: (EVERY YEAR)		—

NOTE: (1) Replace every 30 operating days or every 3 months, whichever comes first.

(2) Service more frequently when riding in dusty areas.

(3) Service more frequently after riding in very wet or muddy conditions.