

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	DRIVE CHAIN	I.L	I.L	53
*	BRAKE PADS	NOTE (3)	I: (EVERY YEAR)	50
	CHAIN SLIDER	I	I	54
	FRONT FORK OIL/AIR		R: (EVERY YEAR)	15
	FRONT/REAR BRAKE FLUID	I	I R: (EVERY YEAR)	48
*	SUSPENSION		I	—
	SWINGARM BEARING	I.L	I.L	—
	BRAKE SYSTEM	I	I	48
*	CLUTCH	A	A	46
*	SPARK ARRESTER		C	56
	ALL NUTS, BOLTS, FASTENERS	I	I	—
	LIGHTING EQUIPMENT	I	I	—
	TIRES	I	I	13
*	STEERING HEAD BEARING		A: (EVERY YEAR)	—
**	REAR BRAKE PIVOTS		I: (EVERY YEAR)	—

NOTE: (1) Replace every 30 operating days or every 3 months, whichever comes first.
(2) Service more frequently when riding in dusty areas, sand or snow.
(3) Service more frequently after riding in very wet or muddy conditions.