




STARTING THE ENGINE



- ① Fuel valve lever
- ② Fuel vent valve

- ③ Ignition/engine stop switch
- ④ Neutral indicator

WARNING

Exhaust contains poisonous carbon monoxide gas. Never run the engine in a closed area.

1. Turn the fuel valve ① "ON", and make sure that the fuel vent valve ② is "ON".
2. Turn the ignition/engine stop switch ③ "ON".
3. Make sure that the transmission is in neutral by lifting the shift lever and checking that the neutral indicator ④ is at "N".

WARNING

Do not try to start the engine with the transmission in gear. You may injure yourself or damage the vehicle.