


STARTING THE ENGINE



- ① Fuel valve lever
- ② Fuel vent valve

③ Ignition switch

④ Neutral indicator

WARNING

Exhaust contains poisonous carbon monoxide gas. Never run the engine in a closed area.

1. Turn the fuel valve ① ON , and make sure that the fuel vent valve ② is ON .
2. Turn the ignition switch ③ ON .
3. Make sure that the transmission is in neutral by lifting the shift lever and checking that the neutral indicator ④ is at N .

WARNING

Do not try to start the engine with the transmission in gear. You may injure yourself or damage the vehicle.