

DRAINING FUEL FROM THE TANK AND CARBURETOR

You may drain all fuel through the carburetor drain tube. This tube is connected to the carburetor float bowl at the left side of the engine and extends downward by the left foot peg.

1. Turn the carburetor fuel valve to the reserve position. This will allow all gasoline in the fuel tank to drain through the carburetor.
2. Place the free end of the carburetor drain tube into a suitable gasoline container.
3. Open the carburetor drain by turning the drain screw knob counterclockwise.
4. When all fuel has been drained from the ATC, close the carburetor drain screw.
5. Turn the carburetor fuel valve to the "S" position.

- ① DRAIN TUBE
- ② DRAIN SCREW
- ③ FUEL VALVE

