


Battery Care

Inspecting and maintaining the electrolyte level should be performed at the mileage intervals indicated in the Maintenance Schedule (page 101) add Pre-riding Inspection (page 30). The electrolyte level must be maintained between the upper (1) and lower (2) level marks. If low, add distilled water to raise the levels. Use a syringe or plastic funnel. The battery is accessible by removing the side cover.

CAUTION: When installing the battery, route the battery breather tube as shown in the figure and be careful not to bend or twist the tube.



Mantenimiento de la batería

La inspección del nivel de electrolito de la batería y, su reposición, deberán efectuarse tan frecuentemente como se indica en el Programa de Mantenimiento (pág. 101), y en la sección "Inspección antes de la puesta en marcha" (Pág. 30). El nivel del electrolito deberá estar entre la marca superior (1) y la inferior (2) del nivel. Si el nivel está más bajo que lo indicado, agregue agua destilada. Utilice una jeringa o embudo plástico. La batería es accesible desmontando la cubierta lateral. **PRECAUCION:** Al instalar la batería, coloque la tubería de respiradero de la batería como se indica en la ilustración y tenga cuidado de no doblar ni torcer la tubería.

(3) ATENCION (4) Tubo de respiradero de la batería

