


Starting Procedure

To restart a warm engine, follow the procedure for “High Air Temperature.”

Normal Air Temperature

10° – 35° C (50° – 95° F)

1. Pull the choke lever (1) back all the way to Fully ON (A), if the engine is cold.
2. With the throttle slightly open, press the starter button.



(1) Choke lever

(A) Fully ON

(B) Fully OFF

NOTE:

- * Do not open the throttle when starting the engine with the choke ON. This will lean the mixture, resulting in hard starting.
3. Warm up the engine by opening and closing the throttle slightly.
 4. About a half minute after the engine starts, push the choke lever (1) forward all the way to Fully OFF (B).
 5. If idling is unstable, open the throttle slightly.