



To set scheduled date:

1. Turn the ignition switch ON.
2. Select the DAYS mode.
3. Press the left control button (1) for more than 2 seconds. The display will be set in the adjustment mode with the year display flashing.



- (1) Left control button
- (2) Right control button

4. To set the year, press the right control button (2) until the desired year appears.
 - Quick setting – press and hold the right control button until the desired year appears.
 - If setting “-” while adjusting year, scheduled date is not set.
5. Press the left control button when the display reaches the desired year. The month display will be flashing.

