


Starting Procedure

To restart a warm engine, follow the procedure for “High Air Temperature.”

Normal Air Temperature

10°–35°C (50°–95°F)

1. Pull the choke knob (1) up all the way to Fully ON (A), if the engine is cold.



(1) Choke knob

(A) Fully ON
(B) Fully OFF

2. Start the engine, leaving the throttle closed.

NOTE:

- * Do not open the throttle when starting the engine with the choke ON. This will lean the mixture, resulting in hard starting at:
2,500 – 4,000 min⁻¹ (rpm)
3. Immediately after the engine starts, operate the choke knob (1) to keep fast idle.
 4. About a half minute after the engine starts, push the choke knob (1) down all the way to Fully OFF (B).
 5. If idling is unstable, open the throttle slightly.