15 CB300FA (U)-32K33K000. book 46 ページ 2014年10月9日 木曜日 午後1時4分

Maintenance Fundamentals

Maintenance

Have your tyres replaced by your dealer. For recommended tyres, air pressure and minimum tread depth, see "Specifications." ₽ P. 105

Follow these guidelines whenever you replace tyres.

- Use the recommended tyres or equivalents of the same size, construction, speed rating, and load range.
- Have the wheel balanced with Honda Genuine balance weights or equivalents after the tyre is installed.
- Do not install a tube inside a tubeless tyre on this motorcycle. Excessive heat build-up can cause the tube to burst.
- Use only tubeless tyres on this motorcycle. The rims are designed for tubeless tyres, and during hard acceleration or braking, a tubetype tyre could slip on the rim and cause the tyre to rapidly deflate.

Installing improper tyres on your motorcycle can adversely affect handling and stability, and can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tyres recommended in this owner's manual.