Keys

Keys

Ignition key

Be sure to record the key number provided with the key number plate and record it in this manual.

Store the spare key in a safe location. To make a duplicate, take the spare key or the key number to your dealer.

If you lose all keys and the key number, the ignition switch assembly will probably have to be removed by your dealer to determine the key number.

A metal key holder may cause damage to the area surrounding the ignition switch.



