

CONTENTS

Serial Number Location	5
Control Location	6
OPERATING INSTRUCTIONS	10
Instruments and Indicator Lamps.....	10
Electrical Controls	13
Main switch	13
Ignition switch	14
Starter switch	14
Headlight switch	14
Stop light switches	15
Horn button	15
Turn signal switch	16
Mechanical Controls	16
Steering lock	16
Seat lock.....	17
Helmet holder	18
Front brake lever.....	18
Throttle grip	18
Rear brake pedal	19
Gear change pedal	20
Clutch lever	21
Kick starter pedal	21