


## TOOL KIT

The tool kit ① is contained in the compartment located in the battery holder case under the seat. Minor adjustment and parts replacement can be performed with the tools contained in the kit. Adjustments or repairs which cannot be performed with these tools should be referred to your HONDA dealer.



① Tool kit      ② Spare fuse holder

Listed below are the items included in the tool kit

- Axle wrench: for axle nuts
- 17×19 mm open end wrench
- 10×14 mm open end wrench
- 8×12 mm open end wrench
- 45 mm pin wrench: for adjustment of rear suspension
- Spark plug wrench
- Pliers
- No. 2 screwdriver
- No. 3 cross point screwdriver
- No. 2 cross point screwdriver
- Screw driver grip: for screwdriver
- Lever: for screwdriver
- Handle: for axle wrench
- Tool bag

Items attached to the motorcycle in a separate package during shipment

- ① A can of touch-up paint
- ② Spare battery fuse (in the spare fuse holder)