

The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:
Current instant fuel mileage. If your speed is less than 7 km/h (5 mph), " --.- " is displayed. When " --.- " is displayed at speeds above 7 km/h (5 mph), go to your dealer for service.
- Average fuel mileage:
Average fuel mileage since tripmeter A was reset. When " --.- " is displayed, go to your dealer for service.
- Fuel consumption:
Total fuel consumption since tripmeter A was reset. When " ---.- " displayed, go to your dealer for service.

▶ **To reset the average fuel mileage and fuel consumption:**  **P.22**