

ITEMS	FREQUENCY	WHICHEVER → COMES		ODOMETER READING [NOTE (1)]								Refer to pages
		FIRST ↓	x 1,000 km x 1,000 mi	1	6	12	18	24	30	36		
		NOTE	MONTH	0.6	4	8	12	16	20	24		
DRIVE CHAIN				EVERY 1,000 km (600 mi) I, L								73
DRIVE CHAIN SLIDER						I		I		I		78
BRAKE FLUID		NOTE (3)			I	I	R	I	I	R		21
BRAKE PAD WEAR					I	I	I	I	I	I		87
BRAKE SYSTEM				I		I		I		I		21, 87
* BRAKE LIGHT SWITCH						I		I		I		—
* HEADLIGHT AIM						I		I		I		—
CLUTCH SYSTEM				I	I	I	I	I	I	I		25
SIDE STAND						I		I		I		79
* SUSPENSION						I		I		I		—
* NUTS, BOLTS, FASTENERS				I		I		I		I		—
** WHEELS/TYRES						I		I		I		—
** STEERING HEAD BEARINGS				I		I		I		I		—