
## **Instruments** (Continued)



Odometer [TOTAL] & Tripmeter [A/B] & Fuel mileage meter & Fuel consumption meter The SEL button selects the odometer, tripmeter A, tripmeter B, current fuel mileage, average fuel mileage and fuel consumption.

► To reset the tripmeter: ► P.24

