

CONTENTS

SERIAL NUMBER LOCATION	5
CONTROL LOCATION	6
OPERATING INSTRUCTIONS	10
Instruments and Indicator Lights	10
Ignition Switch	13
Engine Stop Switch	14
Starter Button	14
Headlight Dimmer Switch	15
Turn Signal Switch	16
Horn Button	16
Steering Lock	16
Seat Lock and Helmet Holder	17
Document Compartment	18
Rear Shock Absorbers	18
FUEL AND OIL	19
Fuel Valve	19
Fuel Tank	20
Engine Oil Recommendation	22
PRE-RIDING INSPECTION	23
TIRE INFORMATION	24
STARTING THE ENGINE	25