


Brake pads

Brake pad wear will depend upon the severity of usage, type of driving, and condition of the roads. It may be expected that the pads will wear faster on dirty and wet roads. Inspect the pads visually during all regular service intervals to determine the pad wear.




(FRONT)

- (1) Brake pads
- (2) Red lines
- (3) Brake disc

Remove the inspection window cap. If any pad is worn to the red line (2), replace all front or rear pads as a set.

NOTE:

Use only genuine Honda replacement friction pads offered by authorized Honda dealers. When service is necessary on the brakes, consult your Honda dealer.



(REAR)