

MAINTENANCE SCHEDULE

The following items require some mechanical knowledge. Certain items (particularly those marked * and * *) may require more technical information and tools. Consult your authorized Honda Dealer.

Perform the Pre-ride Inspection (page 34) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

| ITEMS | FREQUENCY | WHICHEVER → COMES FIRST ↓ NOTE | ODOMETER READING [NOTE (1)] | | | | | | | | Refer to pages |
|-------------------------------|-----------|--------------------------------------------|-----------------------------|-----|----|----|----|----|----|-------|----------------------|
| | | | x 1.000 km | 1 | 6 | 12 | 18 | 24 | 30 | 36 | |
| | | | x 1.000 mi | 0.6 | 4 | 8 | 12 | 16 | 20 | 24 | |
| | | MONTHS | 6 | 12 | 18 | 24 | 30 | 36 | | | |
| * FUEL LINE | | | | | I | | I | | I | — | |
| * FUEL STRAINER SCREEN | | | | C | C | C | C | C | C | — | |
| * THROTTLE OPERATION | | | | | I | | I | | I | 57 | |
| * CARBURETOR CHOKE | | | | | I | | I | | I | — | |
| AIR CLEANER | NOTE (2) | | | | | R | | | R | 59 | |
| CRANKCASE BREATHER | NOTE (3) | | | C | C | C | C | C | C | 54 | |
| SPARK PLUG | | | | I | R | I | R | I | R | 55-56 | |
| ENGINE OIL | | | R | R | R | R | R | R | R | 51-54 | |
| ENGINE OIL FILTER | | | R | | R | | R | | R | 52-53 | |
| * CARBURETOR SYNCHRONIZATION | | | | | I | | I | | I | — | |
| * CARBURETOR IDLE SPEED | | | I | I | I | I | I | I | I | 58 | |
| * SECONDARY AIR SUPPLY SYSTEM | NOTE (4) | | | | I | | I | | I | — | |