


## ■ OPERATING INSTRUCTIONS

### ● Instruments and Indicator Lights

The instruments are mounted above the headlight and the indicator lamps are mounted in the upper holder of handlebars.

Their functions and operating methods are described in the table in the next page.



- ① Tachometer
- ①-a Tachometer RED zone
- ② Speedometer
- ③ Odometer
- ④ Trip-meter
- ④-a Trip-meter reset knob
- ⑤ High beam indicator lamp
- ⑥ Turn signal indicator lamp
- ⑦ Oil pressure warning lamp
- ⑧ Neutral indicator lamp

