


## Front and Rear Suspension Inspection

1. Check the front fork assembly by locking the front brake and pumping the fork up and down vigorously. Suspension action should be smooth and there must be no oil seepage.
2. Swingarm bushing—this can be checked by pushing hard against the side of the rear wheel while the motorcycle is on the center stand and feeling for looseness of the fork bushings.
3. Carefully inspect all front and rear suspension fasteners for tightness.

## Side Stand

Check the rubber pad for deterioration or wear. Replace if any wear extends to the wear line (1) as shown.



## Inspección de las suspensiones delantera y trasera

1. Revise el conjunto de horquilla delantera bloqueando el freno delantero y bombeando la horquilla hacia arriba y abajo vigorosamente. La acción de la suspensión deberá ser suave y no deberá haber ninguna filtración del aceite.
2. Casquillo del brazo oscilante — La revisión de esta parte puede efectuarse empujando fuertemente el lado de la rueda trasera mientras que la motocicleta esté apoyada en el soporte central y palpando los casquillos de la horquilla para detectar alguna flojedad.
3. Inspeccione cuidadosamente el ajuste de todos los sujetadores de las suspensiones delantera y trasera.

## Soporte lateral

Revise el taco de goma por si está deteriorado o desgastado. Cámbielo si el desgaste se pasa de la línea de desgaste (1), según se muestra.