

## **Tires: tubeless**

This motorcycle is equipped with tubeless tires, valves, and wheel rims. Use only tire marked "TUBELESS TIRE APPLICABLE" and tubeless valves on rims marked "TUBELESS TIRE APPLICABLE".

### Inspection:

Proper air pressure will provide maximum stability, riding comfort and tire life. Check the pressures frequently and adjust if necessary.

**NOTE: Check tire pressure when the tires are "cold," before you ride.**

Check the tires for cuts, imbedded nails or other sharp objects. Check the rims for dents or deformation. If there is any damage, see your authorized Honda dealer for repair, replacement, and balancing.

---

## **Neumáticos: sin cámara**

Esta moto está equipada con neumáticos sin cámara, válvulas, y llantas de rueda. Use sólo los neumáticos marcados "TUBELESS" y las válvulas para neumáticos sin cámara para llantas marcadas "TUBELESS TIRE APPLICABLE".

### Inspección:

La presión adecuada de aire proporciona la máxima estabilidad, confort de conducción y vida útil de los neumáticos. Revise frecuentemente la presión de neumáticos y ajústela, si necesario.

**NOTA: Revise la presión del neumático cuando éste está todavía "frío" antes de comenzar la conducción.** Revise los neumáticos para detectar algunos cortes, clavos embutidos u otros objetos afilados. Revise las llantas para detectar abolladuras o deformaciones. Si se observa algún daño, consulte a su concesionario HONDA respecto a las reparaciones, reemplazo, y puesta en equilibrio.