

| <b>(Ref.No.) Description</b>            | <b>Function</b>   |
|---|---|
| (5) Fuel indicator (orange)             | Lights when there is only few fuel left in the fuel tank. The amount of fuel left in the tank when lights and with the vehicle set upright is approximately:<br>3.5 ℓ (0.92 US gal , 0.77 Imp gal)  |
| (6) Tachometer                          | Shows engine revolutions per minute.  |
| (7) Tachometer red zone                 | Never allow the tachometer needle to enter the red zone, even after the engine has been broken in.<br><br><b>NOTICE</b><br>Running the engine beyond recommended maximum engine speed (the beginning of the tachometer red zone) can damage the engine. |
| (8) Coolant temperature gauge           | Shows coolant temperature (page 16 ).   |
| (9) Right turn signal indicator (green) | Flashes when the right turn signal operates.  |