

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH	6	12	18	24	30	36			
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	90	
* CHOKE OPERATION					I		I		I	—	
AIR CLEANER		NOTE (2)					C		C	92	
CRANKCASE BREATHER		NOTE (3)			C	C	C	C	C	86	
SPARK PLUGS					I		R		I	87	
* VALVE CLEARANCE							I			—	
ENGINE OIL					R		R		R	82	
ENGINE OIL FILTER					R		R		R	83	
* ENGINE IDLE SPEED					I	I	I	I	I	91	
RADIATOR COOLANT		NOTE (4)					I		R	31	
* COOLING SYSTEM							I		I	—	
* SECONDARY AIR SUPPLY SYSTEM							I		I	—	