

OPERATION

Page

1	MOTORCYCLE SAFETY
1	Important safety information
2	Protective apparel
4	Load Limits and Guidelines
8	PARTS LOCATION
11	Instruments and Indicators
20	MAJOR COMPONENTS (Information you need to operate this motorcycle)
20	Suspension
21	Brakes
24	Clutch
26	Coolant
28	Fuel
31	Engine Oil
32	Tubeless Tyres
38	ESSENTIAL INDIVIDUAL COMPONENTS
38	Ignition Switch
39	Keys
41	Immobilizer System (HISS)
44	Right Handlebar Controls
46	Left Handlebar Controls

Page

47	FEATURES (Not required for operation)
47	Steering lock
48	Windshield height adjustment
48	Handlebar adjustment
49	Helmet Holder
50	Seat
51	Adjusting the front seat height
51	Compartment to store a U-shaped anti-theft lock
52	Document Compartment
53	Side cover
54	Removal of half fairings
55	Removal of inner panel
56	Clip
57	Headlight aim vertical adjustment
58	OPERATION
58	Pre-ride Inspection
60	Starting the Engine
63	Running-in
64	Riding
65	Braking
69	Parking
70	Anti-theft Tips