

8. Lights and horn - check that the headlight, tail/brake light, turn signals, indicators and horn function properly.
9. Engine stop switch - check for proper function (page 44).
10. Side stand ignition cut-off system-check for proper function (page 99).