

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
* FUEL LINE					I		I		I	*	
* FUEL STRAINER SCREEN				C	C	C	C	C	C	*	
* THROTTLE OPERATION					I		I		I	76	
* CHOKE OPERATION					I		I		I	*	
AIR CLEANER	NOTE (2)			C	C	R	C	C	R	66	
CRANKCASE BREATHER	NOTE (3)			C	C	C	C	C	C	67	
SPARK PLUG					R		R		R	74	
* VALVE CLEARANCE					I		I		I	*	
ENGINE OIL			R		R		R		R	68	
ENGINE OIL FILTER			R		R		R		R	71	
* ENGINE IDLE SPEED			I	I	I	I	I	I	I	77	
* SECONDARY AIR SUPPLY SYSTEM					I		I		I	*	