




## Hazard lights switch

This system must be used only when your motorcycle is stopped in an emergency. To activate it set the ignition switch to ON or  and then press the button . The front and rear turn signals will flash simultaneously.

Set the switch to OFF if the hazard lights are no longer needed or if the turn signals are not working correctly and could cause confusion among other road users.



(1) Hazard lights switch