## THROTTLE OPERATION

Refer to the Safety Precautions on page 64.

- Check for smooth rotation of the throttle grip from the fully open to the fully closed position at both full steering positions.
- 2. Measure the throttle grip free play at the throttle grip flange.

The standard free play should be approximately:

2.0-6.0 mm

To adjust the free play, loosen the lock nut (1) and turn the adjuster (2).

