

Installation Notes :

Position the front wheel between the fork legs and insert the axle from the left side, through the left fork leg and wheel hub.

**CAUTION:**

- \* **When installing the wheel, fit the left brake disc carefully between the brake pads to avoid damaging the pads.**

Tighten the axle bolt to the specified torque.

Front axle torque :

60 N·m (6.0 kg-m , 43 lb-ft)

Fit the right caliper over the disc, taking care not to damage the brake pads. Install the caliper mounting bolts and tighten to a torque of:

27 N·m (2.7 kg-m , 20 lb-ft)