

ITEM	FREQUENCY	WHICHEVER →	ODOMETER READING [NOTE(1)]							REFER TO PAGE		
			COMES FIRST ↓	x1,000km	1	6	12	18	24		30	36
			NOTE	x1,000mi	0.6	4	8	12	16		20	24
			MONTH		6	12	18	24	30	36		
	DRIVE CHAIN			I, L, EVERY 1,000 km (600 mi)							73-77	
	DRIVE CHAIN SLIDER					I		I		I	78	
	BATTERY				I	I	I	I	I	I	91-93	
	BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R	17-20	
	BRAKE PAD WEAR				I	I	I	I	I	I	88	
	BRAKE SYSTEM			I		I		I		I	17-20,90	
*	BRAKE LIGHT SWITCH					I		I		I	96	
*	HEADLIGHT AIM					I		I		I	-	
	CLUTCH SYSTEM					I		I		I	21	
	CLUTCH FLUID	(NOTE 4)			I	I	R	I	I	R	21	
	SIDE STAND					I		I		I	79	
*	SUSPENSION					I		I		I	78	
*	NUTS, BOLTS, FASTENERS			I		I		I		I	-	
**	WHEELS/TYRES					I		I		I	-	
**	STEERING HEAD BEARINGS			I		I		I		I	-	